

## General Information

Reflexite® GP 214 tapes are microprismatic retroreflective tapes, used to reflectorize garments. Changes in product performance due to modifications in the specified process are the responsibility of the user. The suitability of the intended care process must be determined.

Reflexite® GP 214 cleans as well at lower temperature as it does at higher temperatures. Therefore select the lowest washing temperature that will ensure adequate cleaning of the fabric. This will allow environmentally friendly washing and will extend the life of the garment. Variations in environmental conditions as well as chosen care process may affect the life of your garment.

## Recommended Care Symbols

Reflexite® GP 214 will withstand a minimum of 25 washings at 40° C when attached to a variety of background materials.



## Hand Washing

Hand washing can be done with a sponge, a soft fabric cloth or a soft brush with lukewarm water and a mild detergent. After washing, the tape must be rinsed with clean water.

Stubborn stains such as grease or tar may be spot cleaned with petrol, alcohol, naphtha or turpentine. After spot cleaning the tape must be hand washed as above and rinsed with water.

## Household Washing

Washer: Standard household washing machine

Temperature: 30° C to 40° C

Detergent: Standard household detergent, which contains oxygen bleach to reduce staining with hi-vis garments.

Setting: "Coloured clothing without pre-wash"

Maximum washing time on highest temperature is not to exceed 12 minutes.

Maximum total washing time is not to exceed 50 minutes.

If Reflexite® GP 214 tapes are used on easily outbleeding fabrics, we recommend to conduct the first two washes at 30° C. This can prevent colour staining.

## Bleaching

Do not bleach.

## Drying

Household tumble dryer, normal, low heat.

Dry to "slightly humid". DO NOT OVER DRY.

Maximum exhaust temperature shall not exceed 80° C.

For extended life, garment should be turned inside out before drying.

## Chemical Cleaning / Dry Cleaning

Do not dry clean.

### IMPORTANT NOTICE

All Reflexite® and ORALITE® products are subject to careful quality control throughout the manufacturing process and are warranted to be of merchantable quality and free from manufacturing defects. Published information concerning Reflexite® and ORALITE® products is based upon research which the Company believes to be reliable although such information does not constitute a warranty. Because of the variety of uses of Reflexite® and ORALITE® products and the continuing development of new applications, the purchaser should carefully consider the suitability and performance of the product for each intended use, and the purchaser shall assume all risks regarding such use. All specifications are subject to change without prior notice.

Reflexite® is a registered trademark of ORAFOL Europe GmbH.

