

General Information

Reflexite® FTP 1200 Advanced is a microprismatic retroreflective tape, used to reflectorize fire-fighter's garments, and is fully certified to meet the requirements of EN 469:2005 and EN ISO 20471:2013.

Reflexite® FTP 1200 Advanced is certified for 30 wash cycles according to EN ISO 20471:2013. Changes in product performance due to modifications in the specified process are the responsibility of the user. The suitability of the intended care process must be determined by the end user.

Reflexite® FTP 1200 Advanced cleans as well at lower temperature as it does at higher temperatures. Therefore select the lowest washing temperature that will ensure adequate cleaning of the fabric. This will allow environmentally friendly washing and will exceed the life of the garment.

Variations in environmental conditions as well as chosen care process may affect the life of the garment.

Care Instructions



Hand Washing

Hand washing can be done with a sponge, a soft fabric cloth or a soft brush with lukewarm water and a mild detergent. After washing, the tape must be rinsed with clean water.

Household Washing

Recommended washing method is ISO 6330:2012 Method 2A

Washer: Standard household washing machine

Temperature: 40° or 60° C

Detergent: Standard household detergent

Setting: "Coloured clothing without pre-wash"

Maximum washing time on highest temperature is not to exceed 12 minutes.

Maximum total washing time is not to exceed 50 minutes.

Bleaching

Only non-chlorine bleach when needed.

Drying

Use a household tumble dryer, Normal, low or medium heat.

Dry to "slightly humid". DO NOT OVER DRY!

Maximum exhaust temperature shall not exceed 80° C.

For extended life, garment should be turned inside out before drying

Fire garments are sometimes dried in a static drying room where cool air is blown into the inside of the jacket and the jacket is dried from the inside out.

Ironing

Do not use steam.

Use a cool or warm temperature setting.

Avoid direct contact of the tape when ironing, use a press cloth.

Chemical Cleaning / Dry Cleaning

Do not dry clean.

IMPORTANT NOTICE

All Reflexite® and ORALITE® products are subject to careful quality control throughout the manufacturing process and are warranted to be of merchantable quality and free from manufacturing defects. Published information concerning Reflexite® and ORALITE® products is based upon research which the Company believes to be reliable although such information does not constitute a warranty. Because of the variety of uses of Reflexite® and ORALITE® products and the continuing development of new applications, the purchaser should carefully consider the suitability and performance of the product for each intended use, and the purchaser shall assume all risks regarding such use.

All specifications are subject to change without prior notice.

Reflexite® is a registered trademark of ORAFOL Europe GmbH.

